# LITHIUM JUMP-STARTER & USB POWER BANK **INSTRUCTION MANUAL**



## SAVE THIS INSTRUCTION MANUAL FOR FUTURE

© 2025 Baccus Global LLC Boca Raton, FL 33432 (877) <u>571-2</u>391



Interletics, and (2) this centre flows accept any interletic exerved, involuting interletics are large dates underselved operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not histalled and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

\* Reorient or relocate the receiving antenna.

- Neuroland the receivering allients of increase the separation between equipment and receiver.
   Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
   Consult the dealer or an experienced radio/TV technician for help.
- hanges or modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

#### SAFETY GUIDELINES / DEFINITIONS **DANGER:** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious

**OWARNING:** Indicates a potentially hazardous situation which, if not avoided, could result in death or

**QCAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in injury.

CAUTION: Used without the safety alert symbol indicates potentially hazardous situation which, if not avoided,

RISK OF UNSAFE OPERATION. When using tools or equipment, basic safety precautions should always be followed to reduce the risk of personal injury. Improper operation, maintenance or modification of tools or equipment could result in serious injury and property damage. There are certain applications for which tools and equipment are designed. Manufacturer strongly recommends that this product NOT be modified and/or used for any application other than for which it was designed. Read and understand all warnings and operating instructions before using any tool or equipment.

#### READ ALL INSTRUCTIONS

WARNING: Read and understand this instruction manual before using this unit. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

## IMPORTANT SAFETY INSTRUCTIONS

#### **GENERAL SAFETY WARNINGS AND INSTRUCTIONS**

**WARNING** - When using electrical appliances, basic precautions should always be followed, including

•The jump-starter and supplied charging cable are not toys and cannot be played with as toys. To reduce the risk of injury, close supervision is necessary when these units are used near children. •Use only attachments recommended or sold by the manufacturer.

**WARNING** - To reduce the risk of electric shock:

•The Smart Cables Controller and Smart Cables Port are always "live"! NEVER insert fingers into the sockets or attempt to disassemble the unit.

• Do not put the unit in water or other liquid. Do not place or store this unit where it can fall or be pulled into water. Do not expose it to rain, snow or use when wet. Charge indoors only.

•Use only the USB charging cable supplied by the manufacturer to recharge. **WARNING -** RISK OF FIRE, ELECTRIC SHOCK, BURST HAZARD, OR INJURY TO PERSONS OR

• Avoid dangerous environments. Do not use appliances in damp or wet locations. Do not use appliances in the rain. Keep children away. All visitors should be kept at a distance from work area. Dress properly. Do not wear loose clothing or jewelry. They can be caught in moving parts. Rubber gloves and

substantial, non-skid footwear are recommended when working outdoors. Wear protective hair covering to contain •Store idle appliance indoors. When not in use, appliances should be stored indoors in a dry and high or locked-up

•Do not abuse cord. Never carry appliance by cord or yank it to disconnect from receptacle. Keep cord from heat,

oil, and sharp edges. Disconnect appliances. Disconnect the appliance from the power supply when not in use, before servicing, and

when changing accessories. •Use of accessories and attachments. The use of any accessory or attachment not recommended for use with this

appliance could be hazardous. Refer to the accessory section of this manual for further details.

 Stay alert. Use common sense. Do not operate this equipment when you are tired or impaired Check for damaged parts. Do not use if damaged in any way.

Do not operate this appliance near flammable liquids or in gaseous or explosive atmospheres.

•Never submerge this unit in water, do not expose it to rain, snow or use when wet or if it has become wet. •To reduce risk of electric shock, disconnect the unit from any power source before attempting maintenance or cleaning. Turning off controls without disconnecting will not reduce this risk.

•This equipment employs parts (switches, relays, etc.) that produce arcs or sparks. Therefore, if used in a garage or enclosed area, the unit MUST be placed not less than 18 inches above the floor.

## SPECIFIC SAFETY INSTRUCTIONS FOR LITHIUM BATTERIES

**WARNING** - To reduce the risk of fire, electric shock, burst hazard, or injury to persons or property: Lithium batteries are small, compact and ideal for providing long-lasting power to this unit. However, they must be used and charged properly. Improper use can result in serious injury, fire, or death.

•Lithium batteries can explode in the presence of a source of ignition. Do not use the product in the presence of • Do not place this lithium battery powered unit in fire or apply heat to it.

• Do not subject this lithium battery powered unit to strong impacts or shocks. The battery in this unit contains safety

and protection devices which, if damaged, may cause the battery to generate heat, rupture or ignite. •Do not expose this lithium battery powered unit to water or salt water, or allow the battery to get wet.

 Avoid storing this lithium battery powered unit in the basement, bathroom or other areas of the house that are or may become wet or humid or where moisture may concentrate.

•Do not leave this lithium battery powered unit in direct sunlight, or use or store the unit inside cars in hot weather. Doing so may cause the battery to generate heat, rupture, or ignite. Using the battery in this manner may also result in a loss of performance and a shortened life expectancy

 Never charge this unit near heat or flammable objects. •NEVER THROW WATER ON A BURNING LITHIUM BATTERY! If a lithium battery does catch on fire, it will burn even more violently if it comes in contact with water or even moisture in the air. A fire extinguisher

## **Battery Charging and Capacity**

This unit is delivered in a partially charged state – you must fully charge it before using it for the first time. When stored at room temperature with a full charge, lithium batteries will begin to discharge from the time they are manufactured, even when unused. Deep discharges also decrease their capacity. Battery life can be extended

 Charge battery to full capacity before storage •Store this unit at temperatures between 5°C and 20°C (41°F and 68°F).

Never discharge the battery fully.

 Charge after each use Always charge at least once every 3-6 months if not in frequent use to prevent overdischarge.

## **Transportation of Lithium Batteries**

·Always check all applicable local, national, and international regulations before transporting a unit containing a

## • Transporting an end-of-life, damaged, or recalled battery may, in certain cases, be specifically limited or

SPECIFIC SAFETY INSTRUCTIONS FOR JUMP-STARTERS **♠ WARNING:** Burst hazard Do not use the unit for charging dry-cell batteries that are commonly used with home appliances. These batteries may burst and cause injury to persons and damage property. Use the unit for charging/boosting a lead-acid battery

onlý. It is not intended to supply power to a low-voltage electrical system other than in a starter-motor application. •Use of an attachment not supplied, recommended or sold by manufacturer specifically for use with this unit may result in a risk of electrical shock and injury to persons. ● WARNING: Risk of explosive gases

#### Working in the vicinity of a lead acid battery is dangerous. Batteries generate explosive gases during normal battery operation. For this reason, it is of the utmost importance that each time before using the jump-starter you read this manual and follow instructions exactly.

•To reduce the risk of battery explosion, follow these instructions and those published by the battery manufacturer

and manufacturer of any equipment you intend to use in the vicinity of the battery. Review cautionary markings on these products and on the engine.

## ● CAUTION - To reduce the risk of injury or property damage: •NEVER ATTEMPT TO JUMP-START OR CHARGE A FROZEN BATTERY.

•Do not operate unit with damaged cord or plug; or if the unit has received a sharp blow, been dropped, or otherwise damaged in any way. Do not disassemble the unit. Opening the unit may result in a risk of electric shock or fire, and will void warranty.

• Make sure the cord is located so that it will not be stepped on, tripped over or otherwise subjected to damage or

• Do not leave the unit unattended while in use • Pull by the plug rather than the cord when disconnecting the USB Charging Cable.

Vehicles that have on-board computerized systems may be damaged if vehicle battery is jump-started. Before

jump-starting, read the vehicle's owner's manual to confirm that external-starting assistance is suitable. This system is designed to be used only on vehicles with a 12 volt DC lead-acid battery system. Do not connect to a 6 volt or 24 volt battery system.

•Excessive engine cranking can damage the vehicle's starter motor. If the engine fails to start after the recommended number of attempts, discontinue jump-start procedure and look for other problems that need to

• Do not use this battery booster on a watercraft. It is not qualified for marine applications.

 Never allow battery acid to come in contact with this unit •Do not operate this unit in a closed area or restrict ventilation in any way.

## INSTRUCTIONS PERTAINING TO THE

**USB PORTS** 

IMPORTANT: Some household USB-powered electronics will not operate with the USB ports provided with this unit. Check the manual of the corresponding electronic devices (including phones, tablets, etc.) to confirm that they can be used with one of these USB ports and which USB port to use (Type A or Type C). •The USB ports do not support data communication. They only provide power to an external USB powered

Do not use this unit to operate appliances that require more than 15W for the USB-A Port; and up to PD 30W when using the USB-C Port only; total 15W output on both the USB-A and USB-C when they are used

Make sure the rating of equipment plugged into the USB port does not exceed the amperage stated. •Do not attach USB hubs allowing connection of multiple personal electronic devices to any of the USB ports on

•Do not insert foreign objects into any of the USB Ports.

#### **FIRST AID**

. When working with lead acid batteries, always make sure immediate assistance is available in case of accident or

Aliways have protective eyewear when using this product: contact with battery acid may cause blindness and/or severe burns. Be aware of first aid procedures in case of accidental contact with battery acid.

• Have plenty of fresh water and soap nearby in case battery acid contacts skin. •Remove personal metal items such as rings, bracelets, necklaces and watches when working with a lead acid battery. A lead acid battery can produce a short circuit current high enough to weld a ring, or similar metal object

•Stay clear of fan blades, belts, pulleys, and other parts that can cause injury to persons. • Be extra cautious to avoid dropping a metal tool onto the battery. It might spark or short-circuit the battery or another electrical part, and that may cause an explosion.

• Never smoke or allow a spark or flame in vicinity of vehicle battery, engine or battery charger. SKIN: If battery acid contacts skin or clothing, wash immediately with soap and water for at least 10 minutes. If

redness, pain, or irritation occurs, seek immediate medical attention. EYES: If battery acid comes in contact with eyes, flush eyes immediately, for a minimum of 15 minutes and seek

#### SAVE THESE INSTRUCTIONS

WARNING - To reduce the risk of injury: Follow these instructions and those published by the battery manufacturer and manufacturer of any equipment you intend to use with this unit. Review cautionary markings on these products and on engine.

#### INTRODUCTION


Congratulations on purchasing your new Lithium Jump-Starter / Power Bank. Read this Instruction Manual and follow the instructions carefully before using this unit. IMPORTANT NOTES:

Several factors can affect a jump-starter's ability to boost a vehicle's battery, including, but not limited to the size
of the battery, the temperature (hot or cold), whether the battery is damaged or defective, and whether the jump-

•The jump-starter requires a minimum voltage to detect the correct connection before it will begin to boost. If the vehicle battery voltage is below approximately 2 volts, it may not be able to detect connection and may not be able to start the vehicle. While this low battery voltage is rare it may occur under extreme conditions.

### **FEATURES**





- 1. LED Light Power Button
- LED Indicators 3. Negative (-) Black Clamp
- 4. Positive (+) Red Clamp Smart Cables Connector
- 6. Type A USB Port 7. Type C USB Port LED Light

## 9. USB Charging Cable

## **VIEWING BATTERY STATUS**

- The Battery Status LED Indicators indicate the battery charge level as follows •If the battery charge level is at full capacity, all three Battery Status LED Indicators light.
- •If the battery is at partial charged, two Battery Status LED Indicators light.
- •If the battery is nearly empty, only one Battery Status LED Indicator lights. The unit should be charged at this time

## •If the battery is completely empty, only one Battery Status LED Indicator flashes for 30 seconds. The unit MUST be charged at this time or the unit's built-in low voltage protection will activate and the unit will automatically shut down.

## **CHARGING / RECHARGING**

This unit is shipped in a partially charged state. Charge the unit after purchase, before first use, and after each subseuent use until all three blue Battery Status LED Indicators light.

**IMPORTANT:** When the unit is not in use, we recommend that the battery is charged at least every 3 to 6 months. ● CAUTION - TO AVOID THE RISK OF PROPERTY DAMAGE: Failure to keep the battery charged will cause manent damage and result in poor performance.

•When the Type C USB port is in use in the charging process, the Type A port will have no output. •A 2A USB is required in order to recharge the unit.

 During the charging process, the unit will stop charging if the battery of the unit is overheated due to extensive
use or recharging or too cold (the ambient temperature has dropped below 0°C). In this case, the Battery Status LED Indicators flash rapidly. The charging process will automatically resume after a cool down

CHARGING/RECHARGING USING THE USB CHARGING CABLE

## AND A DEVICE WITH A USB POWER PORT (NOT SUPPLIED) **●WARNING** – Use only with a Listed Class 2 USB power adapter that is compliant with applicable country regulations and international/regional safety standards. Using adapters that do not meet applicable

safety standards could result in injury. IMPORTANT: Always connect the USB Charging Cable to the external device's USB power port BEFORE connecting it to the unit. A 2A USB power source is required in order to recharge the unit.

1. Make sure the Power Button is turned off (the Battery Status LED Indicators are not lit).

2. Insert one end of the USB Charging Cable into an external device's functional USB power port. 3. Lift up the protective cover of the USB ports. Insert the other end of the USB Charging Cable into the unit's

4. When the unit is properly connected, the blue Battery Status LED Indicators will gradually light up (from bottom to top) to indicate the unit is charging.

5. Charge until all three blue Battery Status LED Indicators light.

6. Disconnect the USB charging cable from the device's USB power port and the unit.

7. After a short period of time the unit will automatically shut down. 8. When charging is complete, store the USB Charging Cable in safe place.

## **OPERATING INSTRUCTIONS**

#### **JUMP-STARTING USING THE SMART CABLES Battery Clamp Connection Precautions**

Connect to a heavy gauge metal part of the frame or engine block.

• Connect and disconnect the battery clamps only after unplugging the power source. •Make sure the engine is not running when connecting or disconnecting the battery clamps.

•Never allow clamps to touch each other. •Attach clamps to battery and chassis as indicated in the section "Connecting the Jump-Starter Using the Included

#### **Connecting the Jump-Starter Using the Included Battery Clamps** 1. Position the Smart Cables Controller to reduce risk of damage by the car hood, doors, or moving engine parts.

2. Stay clear of fan blades, belts, pulleys, and other parts that can cause injury to persons. 3. Check polarity of battery posts. The positive (POS, P, +) battery post usually has larger diameter than the

negative (NEG, N, -) post 4. Connect the Smart Cables Connector to the Smart Cables Port. Be especially careful, since both the

Connector and Controller are "live." 5. Connect the positive (RED) clamp from the jump-starter to the positive (POS, P, +) ungrounded battery post. Connect the negative (BLACK) clamp to the negative (NEG, N, -) battery post, the vehicle chassis or engine block away from the battery. Do not connect the clamp to the carburetor, fuel lines or sheet-metal body parts.

Note: If the battery clamps are incorrectly connected with regard to polarity, the Bi-Color Jump-Starter Status Indicator will light red until the clamps are disconnected. Remove the clamps and then reconnect them with correct polarity. 6. When disconnecting the jump-starter, first remove the negative BLACK (-) clamp from the negative battery post or the vehicle chassis, and then remove the positive RED (+) clamp from the positive battery post. Disconnect the double barrel connector of the Smart Cables Controller from the Smart Cables Port of unit. Store the Smart Cables Controller in a safe place.

Take the following steps, observing all cautions and warnings in the "Important Safety Instructions" section at the front of this manual.

1. Turn off vehicle ignition and all accessories (radio, A/C, lights, connected cell phone chargers, etc.). Place vehicle in "park" and set the emergency brake. 2. Make sure all the unit functions are turned off (the Battery Status LED Indicators are not lit) and the USB

Charging Cable is NOT connected. 3. Lift up the protective cover of the unit's Smart Cables Port. Insert the double-barrel Smart Cables Connector into the Smart Cables Port on the unit.

4. Set up the unit as described in the "Connecting the Jump-starter Using Included Battery Clamps" section, observing all warnings and cautions in the "Important Safety Instructions" section.

5. When the unit is properly connected, the Bi-Color Status Indicator on the Smart Cables Controller will light

6. Turn on the ignition and crank the engine in 5-6 second bursts until the engine starts. 7. When the process is completed, disconnect the jump-starter. First remove the negative BLACK (-) clamp from vehicle chassis, and then remove the positive RED (+) clamp from the positive battery post. Disconnect the double barrel Smart Cables Connector from the Smart Cables Port. 8. Store the Smart Cables Controller in a safe place.

9. Recharge the unit fully.

#### IMPORTANT NOTES:

If the battery clamps are incorrectly connected with regard to polarity, the Bi-Color LED Status Indictor will light red until the clamps are disconnected. Remove the clamps and then reconnect them with correct polarity If the voltage of the unit's internal lithium battery is low and has insufficient output power, the Bi-Color LED Status Indictor will light red. Disconnect the unit and fully charge following the directions in the "Charging / Recharging"

If the Smart Cables Controller is overheated, the Bi-Color LED Status Indictor will light red. Disconnect the Battery

Clamps and allow the unit to cool down for a period before resuming any operation If the cranking current and/or time period exceeds the unit's parameters, the Bi-Color LED Status Indictor will flash red for 50 seconds (a cooling down period) before lighting green again (resuming normal operation).

**• CAUTION -** To avoid the risk of property damage: •If the vehicle doesn't start after the first attempt, allow a resting/cooling period of 4 to 5 minutes before making a second attempt. If a second attempt doesn't start the vehicle, discontinue use and look for other problems that need to be corrected. The battery may be damaged.

•NEVER attempt to use the unit to start a vehicle while it is in charging mode. •Using the jump-starter without a car battery installed in the vehicle will damage the vehicle's electrical system.

#### **OPERATING THE USB PORTS**

**IMPORTANT NOTES:** The USB-A Port provides up to 15W output power. The USB-C Port provides up to PD 30W output power. The total output power is up to 15W when the USB-C and USB-A Ports are used

1. Plug a USB-A powered device to the USB-A Port and/or a USB-C powered device to the USB-C Port on the unit.

2. The Battery Status LED Indicators light.

3. Operate the USB powered devices normally.

4. Unplug the USB devices from the USB Ports on the unit. The unit will turn off automatically after a short period

Periodically check the unit's battery status. When the battery level is nearly empty (only one blue Battery Status LED Indicator lights), the unit must be recharged or the unit's built-in low voltage protection will activate briefly before automatic shut down occurs.

Make sure all the unit functions are turned off when the unit is being recharged or stored.

#### **USB Ports Fault Conditions**

When the USB Ports are in use, the unit will monitor for the following fault conditions (on both Ports):

•If a Low Battery Voltage Fault occurs, only one Battery Status LED Indicator flashes for a short period of time before automatic shut down occurs.

•If an Overload Fault or a Short-circuit occurs, the USB Ports will automatically shut down immediately. •If the battery of the unit overheats or is too cold, the USB Ports automatically shut down.

In any of these cases, disconnect the USB-powered device immediately.

- Allow the unit to cool down for several minutes before attempting to use the USB Ports again. If a fault occurs again, make sure that the total draw of all USB devices plugged into the USB Ports does not exceed the maximum rating.

 If an individual USB device is within specifications and the fault occurs, have the USB device checked for malfunction and do not continue to use it with these USB Ports. Notes: This unit's USB Ports do not support data communication. They only provide power to external USB-

. Some USB-powered household electronics may not operate with this USB Port. Check the manual of the corresponding electronic device (including a cell phone, tablet, etc.) to confirm that it can be used with this type

#### **OPERATING THE AREA LIGHT**

- Make sure the unit does not need to be recharged.

The LED Area Light is controlled by the On/Off Power Button. Refer to the "Features" section to locate.

1. Press the Power Button once to turn the Light on at low setting mode.

2. Press the Power Button a second time to use the Light at high setting mode. 3. Press the Power Button a third time to use the Light at at flash mode.

4. Press the Power Button a fourth time to turn the Light off. When the Area Light turns on, the Battery Status LED Indicators light.

Area Light will automatically shut down. **IMPORTANT**: Make sure the Area Light is turned off when the unit is being recharged or stored. If the battery of the unit overheats or is too cold, the Area Light automatically shuts down.

## **CARE AND MAINTENANCE**

All batteries lose energy from self-discharge over time and more rapidly at higher temperatures. When the unit is not in use, we recommend that the battery is charged at least every 3 to 6 months. From time to time wipe the outside of the appliance with a soft cloth. Do not immerse the appliance in water.

Periodically check the unit's battery status. When the battery level is nearly empty (only one blue Battery Status LED Indicator lights), the unit must be recharged or the unit's built-in low voltage protection will activate and the

There are no user-replaceable parts. Periodically inspect the condition of adapters, connectors and wires. Battery replacement/disposal

The battery should last the service life of the unit. Service life is dependent on a number of factors including but not limited to the number of recharge cycles, and proper care and maintenance of the battery by the end user. Contact manufacturer for any information you may need.

SAFE BATTERY DISPOSAL Contains a lithium battery, which must be disposed of properly. Recycling is required. Failure to comply with local, state and federal regulations can result in fines, or imprisonment

#### Please recycle. **OWARNINGS:**

BATTERY REPLACEMENT

•Before disposing of the battery, protect exposed terminals with heavy-duty electrical tape to prevent shorting (shorting can result in injury or fire). •Do not expose battery to fire or intense heat as it may explode.

• Do not dispose of the battery in fire as this may result in an explosion.

**TROUBLESHOOTING** The unit will not charge

to the charging source and to the unit. Check the connection to the power source. Make sure there is good contact. Confirm that there is functioning power source.

#### •The unit may have shut down to protect the battery from overheating after a long period of operation or charging. or too cold (the ambient temperature has dropped below 0°C). Disconnect the USB Charging Cable from the unit and power source. Allow the unit to cool down or warm up for a period before resuming charging.

•Check that all the unit functions are all turned off.

The Jump-Starter will not start the vehicle Check that all the unit functions are all turned off

Make sure a proper polarity cable connection has been established and the Bi-Color Booster Status Indicator on

•The unit may be in over-current / over-time protection. Remove the clamps and restart after a cooling down period of approximately 30 minutes. •The unit may be overheated due to the excessive engine cranking. Make sure all the unit functions are turned off

and allow the unit to cool down before resuming operation. •The vehicle battery may in fault condition and cannot accept starting assistance. The manufacturer recommends taking it to a certified automotive service center for evaluation.

#### Check that the unit has a full charge. Recharge the unit if necessary The LED Light will not operate

• Check that the unit has a full charge. Recharge the unit if necessary.

•Make sure the Power Button has been pressed to turn the LED Light on. •The battery of the unit may overheat or is too cold. Allow the unit to cool down or warm up before resuming operation.

The USB Ports will not operate •Make sure a USB-A powered device is connected to the USB-A Port or a USB-C powered device is connected

•A fault condition exists in one of the USB Ports. Refer to the USB Ports Fault Conditions in the "OPERATING THE USB PORTS" section to remedy any faults. •Make sure the USB device(s) plugged into the USB Ports do not exceed maximum rating.

•The battery of the unit may overheat or is too cold. Allow the unit to cool down or warm up before resuming operation. Some USB-powered household electronics will not operate with these USB charging/power ports. Check the
manual of the corresponding electronic device to confirm that it can be used with this type of USB charging/

#### •Check that the unit has a full charge. Recharge the unit if necessary. •If the unit does not operate after taking the steps given above, contact the manufacturer at (877) 571-2391.

**ACCESSORIES** Recommended accessories for use with this unit may be available from the manufacturer. If you need assistance regarding accessories, please contact manufacturer at 1-877-571-2391. **OWARNING:** The use of any accessory not recommended for use with this appliance could be hazardous.

## TECHNICAL ASSISTANCE

## **ONE-YEAR LIMITED** MANUFACTURER'S WARRANTY

The manufacturer, Baccus Global LLC, warrants this product against defects in materials and workmanship for a period of ONE (1) YEAR commencing from the date of retail purchase by the original end-user purchaser or from the date of delivery of the good, whichever occurs later ("Warranty Period"). If there is a defect and a valid claim is received by the manufacturer within the Warranty Period, the defective product can be replaced in the following ways: (1) Return the product to the manufacturer for replacement. Proof of purchase may be required by manufacturer. (2) Return the product to the retailer where product was purchased for an exchange (provided that the store is a participating retailer). Returns to retailer should be made within the time period of the retailer's return policy for exchanges only. Proof of purchase may be required. Please check with the retailer for their specific return policy regarding returns that are beyond the time set for exchanges. This manufacturer's warranty does not apply to accessories, bulbs, fuses and batteries; defects resulting from normal wear and tear, accidents; damages sustained during shipping; alterations; unauthorized use; neglect, misuse, abuse; and failure to follow instructions for care and maintenance for the product. This manufacturer's warranty gives you, the original retail purchaser, specific legal rights and you may have other

rights which vary from state to state or province to province. This product is not intended for commercial use. To register your product with the manufacturer, please visit www.BaccusGlobal.com.

## **SPECIFICATIONS**

The photos in this manual may differ from the actual unit.

**Jump-Starter / USB Power Bank** 

5VDC 3A / 9VDC 3A / 12VDC 2.5A / 15VDC 2A / 20VDC 1.5A (PD 30W) or 5VDC 2A Max. 5VDC / 9VDC / 12VDC, 15W Max 5VDC 3A / 9VDC 3A / 12VDC 2.5A / 15VDC 2A / 20VDC 1.5A (PD 30W Max.) 5VDC, 15W Max. Lithium polymer, 11.1V DC 32°F to 104°F (0°C to 40°C) -4°F to 104°F (-20°C to 40°C)

> Imported by Baccus Global LLC, 225 NE Mizner Blvd., Suite 301, Boca Raton, FL 33432 www.Baccusglobal.com 1-877-571-2391 RD060425

USB-A and USB-C used simultaneously: Charging Temperature:

USB-C Output